

PARTNER

CARE . TRUST . RESPONSIBILITY

22 November 2013

Version 1.2

Modell: SP-800 / SP-800-BZ

FTP Folder Login

<ftp://ftp.partner-tech.eu/POS-Terminals/SP-8xx-series/SP-800>



PARTNER

CARE . TRUST . RESPONSIBILITY

Index of contents

What kind of Touch is it?	3
Where can I find the touch driver / utility?	3
How can I calibrate the touch?	3
What kind of RAM can I use?	3
Which interface use the MSR?	4
How can I configure the MSR?	4
How can I change the code page of the customer display?	4
Which interface does the customer display use?	4
Is there an OPOS driver available?	4
How can I use the cash drawer?	4
1. You are using the hardware-address	4
2. You want to use the OPOS-driver	5
3. You want to use the virtual COM-port for cash drawer	5
How can I test the cash drawer?	5



CARE . TRUST . RESPONSIBILITY

Where can I find the manuals?

You can download all manuals under the following links.

User Manual: ftp://ftp.partner-tech.eu/POS-Terminals/SP-8xx-series/SP-800/Manuals/SP800_User_Manual_Draft2_20110628.pdf

Service Manual: ftp://ftp.partner-tech.eu/POS-Terminals/SP-8xx-series/SP-800/Manuals/SP-800_Service_Manual_Draft3_20111006.pdf

What kind of Touch is it?

SP-800:

Touch-Panel type: ELO / Resistive
The controller is an: Egalax
Interface: PS/2

SP-800-BZ:

Touch-Panel type: ABON / Resistive
The controller is an: Egalax
Interface: PS/2

Where can I find the touch driver / utility?

The drivers are content of the driver DVD, which you will get with the machine together.

Alternately can you download it from our ftp-server:

<ftp://ftp.partner-tech.eu/POS-Terminals/POS-Driver-DVD/V1.46.rar>

How can I calibrate the touch?

Install the touch driver and then start the touch utility, to perform a calibration.

What kind of RAM can I use?

RAM Type: DDR III SO-Dimm
Max. supported RAM: 4 GB

Which interface use the MSR?

Interface: PS2

How can I configure the MSR?

There is a configuration utility available, which is content of the OPOS-driver:
ftp://ftp.partner-tech.eu/OPOS/OPOSInstall_1.007.0084.0_x86_20120919.zip

How can I change the code page of the customer display?

There is a configuration utility for customer displays available:
ftp://ftp.partner-tech.eu/Customer-Displays/Customer-Display_Settings-Utility_V1.13.zip

Which interface does the customer display use?

Interface: COM6

Is there an OPOS driver available?

Yes, there is an OPOS-driver available. Here can you download it:
ftp://ftp.partner-tech.eu/OPOS/OPOSInstall_1.007.0084.0_x86_20120919.zip

How can I use the cash drawer?

There are three ways available:

1. You use the hardware-address.
2. You use the OPOS-driver
3. You use a virtual COM-port

1. You are using the hardware-address

The hardware-address can you find at the Service-Manual at page 40 or you use the sample-programs to get these address.



CARE . TRUST . RESPONSIBILITY

2. You want to use the OPOS-driver

Please download the OPOS-driver from the link above.

3. You want to use the virtual COM-port for cash drawer

You can download the instructions from our ftp-server: ftp://ftp.partner-tech.eu/POS-Terminals/SP-8xx-series/SP-800/Virtual_Cash-Drawer_V1.0.pdf

How can I test the cash drawer?

You can download a test tool under the following link.

ftp://ftp.partner-tech.eu/POS-Terminals/SP-8xx-series/SP-800/Utility/Cash-Drawer_API_20131111.zip